



**Compact Power bank**  
**PBC103 10000mAh**  
TLL158301  
User guide



**INTO YOUR FUTURE**


## Thank you, for choosing Tellur!

Please read this user manual carefully before using the product and keep it safe for future references.

**Please note!** Damages caused by misuse of the product will not be covered by the product's warranty.

## 1. Technical parameters

### 1.1 Product appearance



### 1.2 Technical specifications

Battery: Li-polymer

Capacity: 10000mAh/37Wh (3.7V)

Micro USB Input: 5V/2.1A

Type-C Input: 5V/2.1A

Type-C Output: 5V/2.1A

USB port 1 Output: 5V/2.1A

USB port 2 Output: 5V/2.1A

Total Output: 5V/2.1A

Dimensions: 149x68x17mm

Weight: 227g

Protection functions: Short circuit, overcharging, overdischarging, overcurrent

Features: Battery level LED indicator

Color: Black

Compatibility: Universal

Package includes: 1 x 10000mAh power bank

1 x USB - Micro-USB cable 26cm, 1 x Manual

## 2. Power display light

Indicator light:

1. Indicator light: There are 4 lights on the device to show the capacity.

⊙ LED flashing

○ LED switch off

● LED lighting



Power bank will check and show the percentage of capacity when power on.  
4 lights stand for: 25 50 75 100 (%)

### Charge the power bank

Display	Indicator light	Capacity percentage	Note
The first light flashes	⊙○○○	0%--25%	The power bank is full charged when all the light is lighting .
1	●○○○	25%--50%	
2	●●○○	50%--75%	
3	●●●○	75%--100%	
4	●●●●	100%	

### Charge the devices

Display	Indicator light	Capacity percentage	Note
The first light flashes	⊙○○○	0%--25%	When the power is close to 5%, the last light flashes until power runs out
1	●○○○	25%--50%	
2	●●○○	50%--75%	
3	●●●○	75%--100%	
4	●●●●	100%	

## 3. Charging instructions

### 3.1 Charge the power bank

•Connect the cable USB port to the charging device and the other end to the Micro USB or Type-C input connector of power bank.

•After connecting, the power bank is automatically charged and the current power level on the battery status indicator flashes. When the battery is fully charged, the status indicator light will be on.

### 3.2 Charge digital equipment

•Check whether the charging voltage of the digital device

matches the discharging voltage of the power bank.

•Select one matching charging cable, connect one end to the power bank output interface, the other end to the digital device, power bank will automatically recognize to charge digital device.

#### **4. Cautions**

1.Please note that the external battery can achieve the best performance only after two to three times the full charge cycles.

2.To extend the performance of the polymer battery, please, extend the charging time by up to 1-2 hours in the first three charge cycles.

3.Please do not attempt to disassemble or modify the product.

4.Please avoid physical damage to the product.

5.Please avoid using this product in the following environments: high temperature, low temperature, low pressure, humidity, dust, strong magnetic field, and long-term exposure to sunlight. We recommend using up to an altitude of 3000 meters, 0°C to 35°C and humidity 5-95%.

6.This product should not be exposed to drip and splashing with water.

7.Please, use a charging cable, specific to the product.

8.Please, comply with relevant local environmental regulations to remove the product and accessories.

9.Please, contact your local retailer or customer service center if you have any questions.

#### **5. Tips**

•If you do not use the power bank for a long time, we recommend you to fully charge the battery then placed it the dry environment with temperature range from 5 - 35 °C, please avoid to directly expose the product in sunlight.



•Please fully discharge then perform full recharging if you have not used the power bank for more than three weeks or the battery life of the product becomes shorter.

#### Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.